

SmartFill system overview

Refueling a vehicle



1.
TO FUEL VEHICLE,
touch the authorised vehicle
key onto the sensor of the
Smart-Fill unit.



2.
If enabled, SmartFill then
requests the vehicle Speedo/
hourmeter reading, which
helps with scheduling
maintenance.



3.
**OPTIONAL SECURITY
FEATURE:** Smart-Fill
requests the driver's pin
number. This allows you to
personalise records.



The driver fuels the vehicle, and when the fuel delivery has finished, the Smart-Fill stores the details in its memory. Smart-Fill will automatically turn the fuel pump off, after a period of no flow.

Creating reports



At the end of each month, or at a time of your choosing, your fuel use data is copied from the Smart-Fill unit to your office computer, using a SD memory card.



You insert the memory card into the memory card reader slot of your computer. The Smart-Fill software transfers the data directly into a spreadsheet format, which you can open in almost any spreadsheet program, such as: Microsoft Excel® or Microsoft Works®

*You can also fit a 3G
phone modem to a
Smart-Fill system and
simply dial into the unit
from your office computer
to download data, or add/
disable keys and pin
numbers etc*